

H5 Emergency Procedures

4th Bramhall (St Michael's) Scout Group

St Michael's Scout Centre, 67 St Michaels Avenue, Bramhall, Stockport, Greater Manchester, SK7 2PG



4thbramhall.org.uk/hallhire

Fire Alarm Sounds

- Leave the building by the nearest exit
- Person in charge of the group to check everyone is out
- The fire assembly point is in the large carpark opposite St Michael's Church
- Dill 999 and ask for the Fire Brigade if needed

Fire

- Sound the alarm by shouting "FIRE"
- Do not try and fight the fire unless safe to do so
- Leave the building by the nearest exit
- Person in charge of the group to check everyone is out
- The fire assembly point is in the large carpark opposite St Michael's Church
- Dill 999 and ask for the Fire Brigade
- Warn the neighbouring houses that there is a fire

Water Leak

- Locate the stop cock under the sink behind the downstairs kitchen door and turn off.

Electrical problems

⚡ DANGER OF DEATH ⚡
3 PHASE 440V AC SUPPLY

ONLY OPEN THE DOORS ON THE FUSE BOARDS DO NOT UNSCREW OR OPEN ANY BOXES

- Open the workshop door with key No. 3
- To isolate locate the Main Switch (Small switch bottom right with 4 wires going in and out of the box) move the switch to the off position.
- To turn back on a tripped circuit look for the switch that is off in Distribution Board A, B, C or D and switch it on, if it won't stay on there is a major fault leave it in the off position and find an alternative outlet.

Gas

- Not installed

Please contact hallhire@4thbramhall.org.uk or you're booking contact immediately with any of the above problems.

4th Bramhall (St Michael's) Scout Group

St Michael's Scout Centre, 67 St Michael's Avenue, Bramhall, SK7 2PG

www.4thbramhall.org.uk

Registered Charity no. 520206